

# X-SENSE



## User Manual

RC01 Remote Controller

SE EN

### Svenska

Denna bruksanvisning innehåller viktig information om hur er X-Sense fjärrkontroll fungerar. Se till att du läser den här bruksanvisningen helt innan du installerar och använder fjärrkontrollen. Om du installerar denna fjärrkontroll för användning av andra, måste du lämna den här bruksanvisningen (eller en kopia av den) hos slutanvändaren.

### Introduktion

Tack för att du köpte vår fjärrkontroll till ert rökvarnarsystem. X-Sense produkter förbättras och produktportföljen utvidgas ständigt, så besök gärna vår hemsida för att ta del av våra nyheter.

RC01 är en dedikerad fjärrkontroll för X-Sense rökvarnare XS01-W vilka är trådlöst sammankopplade. Enheten kontrollerar enkelt de sammankopplade rökvarnarna, vilket sparar användarna ansträngningen att sträcka sig upp och nå till taket för provning av rökvarnarna eller för att aktivera pausfunktionen. Det är skönt att slippa stå på stegar och balansera på stolar om

det är högt till tak. **OBS!** Denna fjärrkontroll passar inte några andra modeller än de som anges enligt ovan.


### Viktiga säkerhetsinstruktioner och riktlinjer

Håll inte in eller blockera testknappen under en längre tid än vad denna bruksanvisning rekommenderar. Tryck heller inte upprepade gånger utan avvakta tills rökvarnarna hinner agera. Ändra under inga omständigheter enheten utan använd produkten för vad den är tänkt till. Använd endast de angivna batterierna och se till att matcha polaritetsmarkeringen vid uppstart och batteribyte.

### Paket innehåll

- 1 x Fjärrkontroll (batteri ingår)
- 1 x Självhäftande tejp
- 1 x Nyckel (för att öppna enheten)
- 2 x Skruv
- 2 x Plugg
- 1 x Bruksanvisning

### Produktöversikt



### Installation av batteri

Öppna den bakre kåpan genom att sätta in den medföljande nyckeln i skåran längst ner på fjärrkontrollens baksida och öppna. Avlägsna isolerings filmen på knappcells-batteriet. Se till att batteriet är korrekt polariserat (matcha plus och minus med markeringarna) placera batteriet i läge och stäng locket.

### Para ihop fjärrkontrollen med X-Sense rökvarnare XS01-W (köpes separat)

1. Skapa en sammankopplad grupp med rökvarnare enligt den bifogade bruksanvisningen.
2. Arbeta sedan endast med två enheter åt gången, en rökvarnare och en fjärrkontroll.
3. Tryck på test- / pausknappen på rökvarnaren fyra gånger, denna enhet kommer att pipa en gång och den röda lysdioden blinkar långsamt, vilket indikerar att den har gått i sammankopplingsläge och väntar på att en ny enhet skall läggas till.

4. Tryck på test- / pausknappen på fjärrkontrollen två gånger, den lysdioden blinkar snabbt, vilket indikerar att den nu söker efter en enhet att sammankoppla sig med.

5. När sammankopplingen har lyckats tänds LED-indikatorn upp på fjärrkontrollen och släcks sedan igen efter cirka 3 sekunder, vilket indikerar att fjärrkontrollen har avslutat sammankopplingen. Rökvarnaren piper en gång och går automatiskt tillbaka i standby-läge.

### Testa den trådlösa anslutningen mellan rökvarnarna

1. Håll ned testknappen inom fjärrkontrollens räckvidd. LED-indikatorn på fjärrkontrollen kommer då att blinka.
2. Efter att rökvarnarna har mottagit signalen (tar cirka 7 sekunder) kommer deras LED-indikatorer att blinka och rökvarnarna kommer att ljuda kontinuerligt.

Släpp testknappen, LED-indikatorn på fjärrkontrollen slutar då att blinka, vilket indikerar att testningen har avslutats och larmljudet kommer upphöra.

### Pausa rökvarnarna

Tryck bara på pausknappen för att tysta rökvarnare när det förekommer larm av kända anledningar till exempel matos, ånga eller liknande, som orsakar störande falsklarm.

**OBS! Pausa aldrig larm som du inte vet ursprunget på, undersök alltid anledning innan paus funktionen nyttjas.**

Under ett larmtillstånd trycker du på pausknappen en gång och alla sammankopplade

enheter med den initierande rökvarnaren kommer att pausas. Tryck ytterligare en gång för att tysta den rökvarnare som initierade larmet. LED-indikatorn på fjärrkontrollen blinkar blått för varje tryckning för att bekräfta att den har mottagit kommandot.

### Testa fjärrkontrollens batteristatus

I standby-läge (icke-alarmerande läge), om du trycker till kort på fjärrkontrollens testknapp svarar LED-indikatorn på fjärrkontrollen med att blinka blått, vilket indikerar normal funktion och batteristatus.

### Tekniska specifikationer

Sändningsfrekvens	868 MHz
Fjärrkontrollområde	15 m
Arbetstemperatur	0-50 °C
Batterityp	3 V CR2032 Litium Batteri
Batteriet räcker	1-år

### Felsökning

Problem	Möjlig orsak	Lösning
Indikatorn på fjärrkontrollen tänds inte när jag trycker på knappen.	Isolationsfilmen på batteriet har inte tagits bort ordentligt.	Tag bort isolationsfilmen.
	Batteriet är inte korrekt installerat (polarisation eller läge).	Ta ur batteriet och sätt in det igen. Se till att kontakterna är rena.
	Batterinivån är låg.	Byt till ett nytt batteri.
Rökvarnarna svarar inte på fjärrkontrollen.	Misslyckad parning.	Koppla ihop fjärrkontrollen och rökvarnarna igen.
	Utanför räckvidd eller störningar från miljön / andra enheter.	Flytta närmare enheterna eller välj en annan plats och försök igen.

**OBS!** Fjärrkontrollens räckvidd beror på många faktorer. Driftsavståndet varierar beroende på den faktiska driftsmiljön eller radiomiljöfaktorer från andra elektroniska enheter i närheten. Undvik kommunikationsproblem eller störningar genom att fundera på eventuella saker som kan påverka radiokommunikationen. Elektromagnetiska vågor kan genereras av ett flertal enheter såsom TV-apparater, induktionskokare eller mikrovågsugnar.

### Miljöskydd

Elektriska avfallsprodukter får aldrig kastas med hushållsavfall. Återvinn enheten och batterier där återvinningsanläggningar finns. Kontakta din lokala myndighet eller återförsäljare för råd om återvinning.



### Tillverkare

X-Sense Innovations Co., Ltd.  
Address: B4-503-D, Tower B, Kexing Science Park, No. 15 Keyuan Road, Technology Park Community, Yuehai Avenue, Nanshan District, Shenzhen, 518057, CHINA  
Email: support@x-sense.com

### Importör

X-Sense Europe B.V.  
Parellaan 2H  
2132WS Hoofddorp  
Netherlands

### Distributör och Service

# Deltronic

Deltronic Security AB  
EA Rosengrens gata 4  
421 31 Västra Frölunda  
Sweden  
+46-31-140800  
info@deltronic.se  
www.deltronic.se



## English

This manual contains important information on how your X-Sense remote control works. Be sure to read this manual completely before installing and using the remote control. If you install this remote control for the use of others, you must leave this manual (or a copy of it) with the end user.

## Introduction

Thank you for purchasing our remote control for your smoke alarm system. X-Sense products are being improved and the product portfolio is constantly being expanded, so feel free to visit our website to take part in our news. RC01 is a dedicated remote control for X-Sense XS01-W smoke alarms that are wirelessly connected. The unit easily controls the interconnected smoke alarms, which saves users the effort of reaching up and reaching towards the ceiling to test alarms or to activate the pause function. It is nice to not have to stand on ladders and balance on chairs if the distance to the ceiling is high. **NOTE!** *This remote control does not fit any models other than those listed above.*


## Important Safety Instructions and Guidelines

Do not hold or block the test button for a longer time than recommended by this manual. Also, do not press repeatedly, and be sure to wait until the smoke alarms have had sufficient time to react. Under no circumstances change the device, and only use the product for what it is intended for. Use only the specified batteries and make sure to match the polarity marking at start-up and battery replacement.

## Package Contents

- 1 × Remote Controller (Battery Included)
- 1 × Adhesive Tape
- 1 × Key
- 2 × Screw
- 2 × Anchor Plug
- 1 × Manual

## Product Overview



## Operating Instructions

### Battery installation

Open the rear cover by inserting the supplied key into the slot at the bottom of the back of the remote control. Remove the insulating film on the button cell battery. Make sure the battery is correctly polarized (match the pluses and minuses with the markings), place the battery in position and close the lid.

## Pair the remote control with X-Sense XS01-W smoke alarms (purchased separately)

1. Create an interconnected group of smoke alarms according to the enclosed operating instructions bi-packed in the smoke device shipping box.
2. Then work with only two units at a time, one smoke alarm and one remote control.
3. Press the test/pause button on the smoke alarm four times, this unit will beep once and the red LED will flash slowly, indicating that it has entered pairing mode and is waiting for a new unit to be added.

4. Press the test/pause button on the remote control twice, and the LED flashes quickly, indicating that it is now searching for a device to connect to.

5. Once pairing is successful, the LED indicator on the remote controller will light up and then turn off in about 3 seconds, indicating that the controller has exited pairing. The smoke alarm in the pairing mode will beep once and automatically enter standby mode.

## Test the wireless connection between the smoke alarms

1. Hold down the test button within the range of the remote control. The LED indicator on the remote control will then flash.
2. After the smoke alarms have received the signal (takes about 7 seconds), their LED indicators will flash, and the smoke alarms will sound continuously.
3. Release the test button, the LED indicator on the remote control will then stop flashing, indicating that testing has ended, and the alarm sound will stop.

## Hush smoke alarms

Just press the hush button to silence the smoke alarms when there are alarms for a known reason, such as fumes from cooking, steam, or the like, which may cause disturbing false alarms.

**NOTE!** *Never hush alarms that you do not know the origin of, and investigate before silencing.*

During an alarm condition, click on the hush button once and all devices paired with the initial smoke alarm will be silenced. Press again to

silence the smoke alarm that initiated the alarm. The LED on the remote control flashes blue for each press to confirm that it has received the command.

## How to test the battery status of the remote control

In standby mode only (non-alarming mode), if you briefly click the test button on the remote control, the LED indicator on the remote control flashes blue, indicating normal operation and sufficient battery level.

## Technical Specifications

Transmission Frequency	868 MHz
Remote Control Range	15 m
Operating Temperature	0-50 °C
Battery Type	3 V CR2032 Lithium Battery
Battery Lifetime	1 year

## Troubleshooting

Issue	Possible Cause	Solution
The indicator on the remote controller does not light up when I press the button.	The insulating film on the battery has not been peeled off.	Peel off the insulating film.
	The battery is not properly installed (polarization or position).	Take out the battery and re-install it again. Make sure the contacts are clean.
Smoke alarms do not respond to the remote controller.	The battery power is low.	Replace with a new battery.
	Out of range or interference from the environment/ other devices.	Pair the remote controller and smoke alarms again. Move to a closer location or another place and try again.

**Note!** *The range of the remote control depends on many factors. The operating distance varies depending on the actual operating environment or radio environment factors from other electronic devices in the vicinity. Avoid communication problems or interruptions by thinking about anything that may affect the radio communication. Electromagnetic waves can be generated by a variety of devices such as televisions, induction cookers or microwave ovens.*

## Environmental Protection

Electrical waste shall never be disposed of with normal household waste. Recycle the unit and batteries where recycling facilities are located. Contact your local authority or dealer for advice on recycling.



## Manufacturer

X-Sense Innovations Co., Ltd.  
Address: B4-503-D, Tower B, Kexing Science Park, No. 15 Keyuan Road, Technology Park Community, Yuehai Avenue, Nanshan District, Shenzhen, 518057, CHINA  
Email: support@x-sense.com

## Importer

X-Sense Europe B.V.  
Parellaan 2H  
2132WS Hoofddorp  
Netherlands

## Distributor and Service

## Deltronic

Deltronic Security AB  
EA Rosengrens gata 4  
421 31 Västra Frölunda  
Sweden  
+46-31-140800  
info@deltronic.se  
www.deltronic.se

